



Crown Under Partial Impression Technique w/out sending partial

Step One : Standard Impression

- 1)** Take a standard impression of the preparation site with the technique of your choice (without partial in place).
- 2)** Take opposing impression and bite registration.

Step Two : Make an index for relation of partial to the crown preparation (do not worry about the margins w/ this index, only pay attention to capturing the clasp(s) and rest(s)).

- 1)** Inject Blu-Mousse Super Fast (recommended to reduce chair time) around the prep site, clasp(s) and rest(s).
- 2)** Once the Blu-Mousse material has set (30 seconds), remove the partial with the index attached and trim the Blu-Mousse material so the outer portion of the clasp(s) and rest(s) are exposed.
- 3)** Trim away any material that does not allow the index to be removed.
- 4)** Remove the index from the partial by pushing index in an apical direction.

Step Three: Temporize the preparation and send the impressions, index, bite registration, and lab slip to Assured Dental Lab.

Send the patient home wearing their partial!